


Bendix® SR-1™ Spring Brake Valve

- Available Remanufactured Exchange
- Maintenance Kit 108123

V.M.R.S. 13-010-048

[SD-03-4508](#)

Reman. Exch. Pc. No.	Service New Pc. No.	Customer Identification	Reservoir Trip Pressure (psi)
286364RX	286364N	NONE	55
288063RX	288063N	IHC-459271-C92	30




Bendix® SR-2™ Trailer Spring Brake Valve

- Available Remanufactured Exchange
- Maintenance Kit 287691

V.M.R.S. 13-010-048

[SD-03-4510](#)

Reman. Exch. Pc. No.	Service New Pc. No.	A P.T.
*287376RX	*287376N	3/4"
102761RX	102761N	3/4"
103061RX	103061N	1/2"



*Does not have trailer service port for anti-compounding.


Bendix® SR-4™ Trailer Spring Brake Valve

- Maintenance Kit 108259

V.M.R.S. 13-010-111

[SD-03-4514](#)

Bendix® SR-4™ Trailer Spring Brake Valve Service New Pc. No.	Bendix® SR-5™ Trailer Spring Brake Valve Service New Pc. No.	A	Comments
107539N	065437	3/4" NPT	With Anti-Compounding
-	065439	1/2" NPT	




Bendix® SR-5™ Trailer Spring Brake Valve

• Maintenance Kit 109015

V.M.R.S. 13-010-048

[SD-03-4516](#)

Reman. Exch. Pc. No.	Service New Pc. No.	A Male (P.T.)	Comments
109615X	K033221	3/4"	With Anti-Compounding
109616X	K033222	3/4"	—
109617X	K033223	1/2"	With Anti-Compounding
109618X	K033224	1/2"	—




Bendix® SR-7® Spring Brake Modulating Valve

[SD-03-4516](#)

Service New Pc. No.	Mounting Stud		Control Port		Balance Port	
	Thd.	Length	Size*	Fitting	Size*	Fitting
K021557	3/8"-16	.94"	1/4" NPT	—	1/4" NPT	—
K021558	3/8"-16	.94"	3/8" NPT	Straight	3/8" NPT	Straight
K021559	3/8"-16	.94"	3/8" PTC	90°	3/8" PTC	Straight
K021560	M10	1.38"	3/8" PTC	90°	3/8" PTC	90°
K021562	—	—	1/4" NPT	—	1/4" NPT	—
K021563	—	—	3/8" PTC	Straight	3/8" PTC	Straight

*PTC - Push-To-Connect Fittings



Bendix® SRC-7000™ Trailer Spring Brake Valve

[SD-03-4656](#)

Service New Pc. No.	Mounting Nipple	Comments
K025778	1/2" NPT	Replaces Sealco® 110500

